



ARC'TERYX

PACK SIZING CHART

For more information on how to select the correct pack size and how to fit your pack, please refer to our Pack Fit Guide on our website at arcteryx.com, or contact a member of our Customer Service Team.

PACK MEASUREMENT CHARTS

MEN'S / UNISEX Pack Sizing Chart

Short SRT | Regular REG | Tall TALL

Back Length	inch	cm	inch	cm	inch	cm	inch	cm	inch	cm	inch	cm	inch	cm	inch	cm		
		14	35.5	15	38	16	40.5	17	43	18	45.5	19	48	20	50.5	21	53	22
	MEN'S / UNISEX - SHORT (SRT)						MEN'S / UNISEX - TALL (TALL)											
	MEN'S / UNISEX - REGULAR (REG)																	

MEN'S / UNISEX Pack Sizing Chart

Short/Regular SHR | Regular/Tall RT

Back Length	inch	cm	inch	cm	inch	cm	inch	cm	inch	cm	inch	cm	inch	cm	inch	cm		
		14	35.5	15	38	16	40.5	17	43	18	45.5	19	48	20	50.5	21	53	22
	MEN'S / UNISEX - SHORT/REGULAR (SHR)						MEN'S / UNISEX - REGULAR/TALL (RT)											

WOMEN'S Pack Sizing Chart

Short SRT | Regular REG | Tall TALL

Back Length	inch	cm	inch	cm	inch	cm	inch	cm	inch	cm	inch	cm	inch	cm	inch	cm		
		14	35.5	15	38	16	40.5	17	43	18	45.5	19	48	20	50.5	21	53	22
	WOMEN'S - SHORT (SRT)				WOMEN'S - TALL (TALL)				WOMEN'S - REGULAR (REG)									

WOMEN'S Pack Sizing Chart

Short/Regular SHR | Regular/Tall RT

Back Length	inch	cm	inch	cm	inch	cm	inch	cm	inch	cm	inch	cm	inch	cm	inch	cm		
		14	35.5	15	38	16	40.5	17	43	18	45.5	19	48	20	50.5	21	53	22
	WOMEN'S - SHORT/REGULAR (SHR)						WOMEN'S - REGULAR/TALL (RT)											

HIPBELT SIZING

	Small		Medium		Large	
	inch	cm	inch	cm	inch	cm
Men's	27 - 32	67 - 80	32 - 37	80 - 92	37 - 42	92 - 105
Women's	25 - 30	63 - 76	27 - 32	76 - 88	30 - 35	88 - 101